









# GREAT WALL - 4WD

V240

Part and Location	Description	Approx Lift Heights	Part No.	Qty Per Vehicle	
<b>Shock Absorbers</b>					
Front 		35mm Gas Bulged Shock Absorbers	STD	<b>SA35667GL</b>	2 ea
		35mm Foam Cell Shocks (plastic shroud)	RSD	<b>SA35643FC</b>	
Rear 		35mm Gas Shock Absorbers		<b>SA12636GL</b>	2 ea
		35mm Gas Bulged Shock Absorbers		<b>SA35636GL</b>	
		35mm Foam Cell Shock Absorbers		<b>SA35636FC</b>	
<b>Torsion Bars</b>		Length			
Front		<b>Increased Rate Bars</b> (Refer part no.TB1550)	1140mm	<b>HOLD005B</b>	1 pr
<b>Leaf Springs</b>					
Rear		Raised Height Comfort 5 + 2 Leaf Springs	50mm	<b>HOLD020T</b>	2 ea
		Special note: HOLD018T Medium Duty Spring with tapered leaves and slipper pads			
		Raised Height H/Duty 5 + 3 Leaf Springs Raised Height H/Duty 6 + 3 Leaf Springs	50mm	<b>HOLD020</b> <b>HOLD020M</b>	2 ea
<b>Shackle Bush Kits</b>					
Rear		Polyurethane Bush Kit		<b>BU728UK</b>	1 kit
<b>U-Bolts</b>					
Rear		Check U Bolt part number with rear springs			4 ea
		Round Form U Bolts (With Nuts) Use UB473 with HOLD018T & HOLD018		<b>UB473</b>	
		Round Form U Bolts (With Nuts) Use UB473-1 with HOLD018M		<b>UB473-1</b>	
<b>Shackle Kits</b>					
Rear		Greaseable Shackle Kits		<b>S386K</b>	2 ea
<b>Pin Kits</b>					
Rear		Greaseable Pins		<b>P387-1</b>	2 ea
<b>Polyair Springs</b>					
Rear		Polyair Bellows Kit (V240 K2 - 2009 onwards)	STD	<b>PA85105</b>	1 ea
			RSD	<b>PA85105R</b>	