



# HOLDEN RODEO - 4WD

RA 4x4 2003 Onwards

Part and Location	Description	Approx Lift Heights	Part No.	Qty Per Vehicle	
<b>Shock Absorbers</b>					
Front 		35mm Gas Bulged Shock Absorbers	STD	<b>SA35667GL</b>	2 ea
		35mm Foam Cell Shocks (plastic shroud)	RSD	<b>SA35643FC</b>	
Rear 		35mm Gas Shock Absorbers		<b>SA12636GL</b>	2 ea
		35mm Gas Bulged Shock Absorbers		<b>SA35636GL</b>	
		35mm Foam Cell Shock Absorbers		<b>SA35636FC</b>	
<b>Torsion Bars</b>		<b>Length</b>			
Front		<b>Increased Rate Bars</b> (Refer part no.TB1550)	1140mm	<b>HOLD005B</b>	1 pr
<b>Leaf Springs</b>					
Rear		Raised Height Comfort 5 + 2 Leaf Springs	50mm	<b>HOLD018T</b>	2 ea
		Special note: HOLD018T Medium Duty Spring with tapered leaves and slipper pads			
		Raised Height H/Duty 5 + 3 Leaf Springs	50mm	<b>HOLD018</b>	2 ea
		Raised Height H/Duty 6 + 3 Leaf Springs		<b>HOLD018M</b>	
Raised Height H/Duty 7 + 3 Leaf Springs	<b>HOLD018MH</b>				
<b>Shackle Bush Kits</b>					
Rear		Polyurethane Bush Kit		<b>BU728UK</b>	1 kit
<b>U-Bolts</b>					
Rear		Check U Bolt part number with rear springs			
		Round Form U Bolts (With Nuts) Use UB473 with HOLD018T & HOLD018		<b>UB473</b>	4 ea
Round Form U Bolts (With Nuts) Use UB473-1 with HOLD018M & MH		<b>UB473-1</b>			
<b>Shackle Kits</b>					
Rear		Greaseable Shackle Kits		<b>S386K</b>	2 ea
<b>Pin Kits</b>					
Rear		Greaseable Pins		<b>P387-1</b>	2 ea
<b>Polyair Springs</b>					
Rear		Polyair Bellows Kit	STD	<b>PA85105</b>	1 ea
			RSD	<b>PA85105R</b>	